

Index

Index

A

Accelerator pedal 5-4
 Accelerator slave cylinder 5-4
 Accessory Air System 4, 5
 Air bag ride height 3-4. *See also* Air Springs; Ride Height
 Air Brake Sending Switches 5-5
 Air brake system 4-1, 4-4, 5-2, 5-4
 Air Compressor 4-4, 5-1
 Air Dryer 5-2
 inspection 5-2
 desiccant cartridge 5-2
 Air filter 1-6
 air restriction indicator 1-6
 Air inlet and exhaust system 1-4
 air-to-air aftercooler 1-1, 1-5
 maintenance 1-5
 Air Line Color Code 5-4
 Air reservoirs 5-3. *See also* Air Tanks
 governor reservoir 5-3
 primary reservoir 5-3
 rear brakes 5-3
 secondary reservoir 5-3
 front brakes 5-3
 Air Springs 3-1, 3-3
 failure 3-1
 replacement 3-3
 Air suspension system 3-19
 Air Suspensions, Troubleshooting 3-5
 Air system 3-1
 Air Tanks 5-3. *See also* air reservoirs
 automatic drain valve 5-3
 check valve 5-3
 manual drain valve 5-3
 mounting 5-3
 Allison MT 643 automatic transmission 2-1
 American Society of Testing Material (ASTM) 1-7
 Anti-rust lubricant 3-8
 Appendix A A-1
 torque chart A-1
 Appendix B B-3
 maintenance checklists B-3
 Appendix C C-7
 drive belts C-7
 Appendix D D-13
 maintenance schedule D-13
 Automatic engine shutdown 1-14. *See also* engine protection module (EPM)
 Automatic height control 3-1, 3-19. *See also* Air Bag Ride Height; Air Springs
 Automatic valves, air 3-1

Axle, drive 3-1
 Axle, front 5-3
 Axle Maintenance and Inspection 3-24
 positioning the Axle 3-24
 wheel stop screws 3-25
 adjustment 3-25
 Axle Shaft Mounting 3-23
 Axle shafts 3-1
 Axle, steer 3-1
 Axles, Front and Rear 3-23
 lubrication 3-23

B

Battery 7-1, 7-5
 hazards 7-1
 deep cycling 7-1
 overcharging 7-1
 sulfation 7-1
 vibration 7-1
 jump starting 7-3
 maintenance 7-2
 precautions 7-3
 removal and replacement 7-4
 troubleshooting 7-2
 Battery, overcharged 7-6
 Battery, undercharged 7-6
 Bennett Shifter 2-1. *See also* Transmission Operations
 Bio-Bar® 1-3. *See also* fuel system
 Block heater 1-13
 Brake Adjustment 4-2
 slack adjuster 4-2
 Brake Inspection 4-4
 Brakes, front 5-6. *See also* air reservoirs
 Brakes, rear 5-6. *See also* air reservoirs
 Braking, Emergency Operation 4-4

C

Caterpillar 3116 diesel engine 1-1, 5-1.
 See also engine
 Charging System 7-1, 7-6
 alternator 7-6
 diode trio 7-10
 drive belts 7-6
 field test 7-9
 troubleshooting 7-6
 voltage regulator 7-6
 inspection and adjustment 7-7
 installation 7-11
 removal 7-10

Chassis 3-3, 4-1, 5-3, 6-1, 7-12, 7-14
 Chassis construction 1-3
 Chassis Inspection 1-6
 Commonly Used Parts 1-8
 Contamination, fuel *See* fuel system
 Contamination, transmission 2-4
 Coolant temperature, engine 1-2
 Cooling system 1-1, 1-7, 6-1
 flushing the system 1-9
 inspection 1-8
 coolant checks 1-8
 fan drive belts 1-9
 hoses 1-8
 radiator checks 1-9
 maintenance 1-8
 radiator shutters 1-5
 shunt line. *See* radiator
 water pump 1-7
 Crankcase capacity 1-12
 Cranking system 7-5
 Cruise Control 5-5
 accelerator pedal 5-6
 brake system 5-6
 indicator lamp 5-6
 operation 5-6
 testing 5-7
 operational test 5-7
 road test and adjustment 5-7
 troubleshooting 5-8
 Zemco AP230 Tester 5-8

D

Diesel fuel grades 1-3
 Dipstick, engine oil 1-11. *See also* Lubrication
 Dipstick, hydraulic 6-2
 Dipstick, transmission 2-4
 Drive Belts. *See* Appendix C
 Drive Shaft 2-12

E

Electric air heater 1-6
 Electrical schematics 7-14
 Electrical system 1-2, 7-1, 7-2
 Engine 1-1
 cold 1-11
 information plates 1-1
 warm 1-11

Engine exhaust 1-4
 Engine mountings 1-14
 Engine oils 1-10. *See also* lubrication; oil viscosity
 American Petroleum Institute 1-10
 Engine Protection Module (EPM) 1-15, 7-12
 EPM override button 1-15
 gauge transmitters 7-13
 mounting 7-13
 TDR failure 7-13
 temperature switch 7-13
 Engine Wiring and Sensors 7-14
 Ethylene glycol 1-8. *See also* cooling system
 Ethylene glycol antifreeze 2-4
 Ethylene Glycol test kits 2-4

F

Fast idle feature 5-4
 Federal Motor Vehicle Safety Standard 4-1
 Front Alignment 3-12
 camber 3-13
 caster 3-13
 king pin inclination 3-13
 steering geometry 3-14
 toe-in 3-13
 Front End Adjustments 3-14
 camber 3-16
 caster 3-16
 frame angle 3-17
 king pin inclinations 3-18
 steering alignment (geometry) 3-18
 toe-in 3-14
 Front End Inspection 3-14
 Front Suspension 3-6
 Front Suspension Attachments 3-7
 radius rods 3-8
 replacement 3-8
 swaybar replacement 3-9
 transverse rod replacement 3-8
 Fuel contamination. *See* fuel system
 Fuel economy 1-11
 Fuel filter element replacement 1-3
 Fuel specifications. *See* fuel system
 Fuel storage tank 1-3
 Fuel Sulfur Content 1-7
 Fuel system 1-1
 bacteria/algae growth 1-3
 fuel injection 1-2
 fuel priming pump 1-2
 Fuel tank 1-2. *See also* fuel system

G

Gauges, air pressure 5-3
 General Warnings 1-2
 Governor, engine 1-1, 1-4
 Governor, air 5-1
 Governor reservoir 5-4

H

High pressure lines 1-2
 Hydraulic Fan Drive System 6-1
 hydraulic fan operation 6-2
 Hydraulic fluid 6-2
 level check 6-7
 Hydraulic Pump 6-1, 6-2
 Hydraulic System 6-1, 6-6
 bleeding 6-4
 inspection 6-3
 quick fixes 6-4

I

Important Safety Information 1-1

L

Lubrication 1-4
 lubrication capacities 1-4
 lubrication points and major components 1-5
 recommended fluids and lubricants 1-5
 Lubrication system 1-1, 1-10
 Luber-finer oil bypass filter 1-13
 maintenance 1-11
 calibrating engine oil dipstick 1-12
 change oil filter 1-12
 changing oil 1-12
 checking oil 1-11

M

Maintenance Check Lists
 2,000 mile service 1-3
 6,000 mile service 1-4
 Maintenance Schedule
 lube key 1-13
 Manual drain valve, air springs 3-21
 MHM 3116 motor home 1-2, 1-1. *See also* chassis
 Mounting, transmission 2-1

N

Neway Rear Suspension 3-21
 air spring removal 3-22
 deflating 3-22
 height control valve adjustment 3-22
 shock absorbers 3-22
 removal 3-22

O

Oil cooler, engine 1-1
 Oil cooler, hydraulic system 6-1
 Oil filter 1-1
 Oil pan 1-10
 Oil pump 1-1
 Oil viscosity 1-1, 1-11. *See also* engine oils
 Outriggers 1-3

P

Parking Brake 4-3
 disabling the parking brake 4-3
 Parking The Coach 2-3
 Power Steering System 6-4. *See also* Hydraulic System
 inspection 6-6
 maintenance 6-7
 troubleshooting 6-7

R

Radiator 1-8
 Rear axle noise 3-23
 Rear Run Box 7-14
 Rear Suspensions 3-19
 Neway 3-19
 pre-operation check 3-19
 Ridewell 3-19
 Reservoir, hydraulic system 6-2
 Ride Height Adjustment 3-2. *See also* Air Bag Ride Height; Ride Height; Air Springs
 proper ride height 3-2
 total ride height 3-2
 Ridewell Rear Suspension 3-20
 air spring removal 3-21
 shock absorber adjustment 3-21
 Road Repairs 3-1
 Rockwell axle 3-6

S

- Service Brakes 4-1. *See also* Brake Adjustment
 - brake chambers 4-1
- Shock Absorbers, Front 3-10
 - inspection and adjustment 3-11
 - removal 3-10
 - replacement 3-12
- Standard height frame 1-2. *See also* Ride Height; Air Springs
- Start switch 1-2, 7-5
- Starter 7-5
- Starting System 7-1, 7-5

U

- Universal Joints 2-12

V

- Valve, check 5-3
- Valve, manual drain 3-3
- Valve, priority 6-1
- Valves; air system regulator 5-4
- Valves, automatic air 3-1
- Valves, automatic drain 5-3
- Vehicle Identification Number 1-3

W

- Water pump 1-7
- Wheel Bearing Adjustment 4-5
 - Dana axles 4-5
 - Rockwell axles 4-5
- Wheel bearings 4-5
- Wheelbase 1-2
- Wheels and Tires 4-6
 - balancing 4-8
 - disk wheel troubleshooting 4-9
 - inflation pressure 4-7
 - tire inspection and maintenance 4-6
 - tire replacement 4-8
 - wheel and stud bolt replacement 4-8
 - aluminum wheels 4-9
 - lug tightening sequence 4-9

