


Chapter 4

Brake and Wheels


Rear Brake System



04-001-00

1.	82-13022-000	Camshaft, RH Frt	1	18.	82-03501-000	Gasket, Chamber Brkt	2
	82-09646-007	Camshaft, LH Frt	1	19.	82-13027-000	Slider Asm, Rr Brake LH/RH	2
2.	82-03379-000	Washer, Spacing	2	20.	82-03283-000	Pin, Shoe Retainer	4
3.	82-03455-000	Pin, Brake Shoe Anchor	4	21.	82-03837-000	Spring, Shoe Retainer	2
	82-03173-000	Locknut	4	22.	82-03200-000	Bolt, Spider Mtg	16
	82-13023-000	Washer, Flat	4		82-04477-000	Washer, Flat	32
4.	82-02241-000	Seal, Camshaft	4		82-03169-000	Locknut, Spider Mtg	16
5.	82-03288-000	Bushing, Anchor Pin	4				
6.	82-03294-000	Bushing, Camshaft	4				
7.	82-03835-000	Spring, Shoe Retainer	4				
8.	82-13024-002	Shoe Asm, Rr Brake	4				
9.	82-09742-000	Kit, 7" Brake Lining	1				
10.	82-03504-000	Roller, Brake Shoe	2				
11.	82-03871-000	Retainer, Roller	2				
12.	82-00155-000	Screw, Cam Brkt	8				
	82-03417-000	Washer, Cam Brkt	8				
13.	82-13026-000	Brkt Asm, LH Chamber	1				
	82-13026-001	Brkt Asm, RH Chamber	1				
	82-00872-000	Fitting, Grease	2				
14.	82-03396-000	Washer, Outer Spacer	2				
15.	53-18094-000	Adjuster, Manual Slack	2				
16.	82-03356-000	Washer, Inner Spacer	6				
17.	82-03344-000	Lockring, Camshaft	2				


Rear Brake Chamber



PA-04-013

1.	82-09634-001	Plug, Release Stud	1
2.	82-09786-001	Stud Asm, Release	1
3.	82-09786-002	Chamber Asm, Upper	1
4.	82-09786-003	Diaphragm, Upper	1
5.	82-09786-004	Adapter Asm	1
6.	82-09737-004	Clamp Asm, Upper	1
7.	82-09686-005	Clamp Asm, Lwr	1
8.	82-09786-006	Diaphragm, Lwr	1
9.	82-09786-007	Rod Asm, Push	1
10.	82-09637-003	Spring, Service Rtn	1
11.	82-09637-000	Housing Asm, Lwr	1
12.	82-09635-003	Boot, Dust	1


Front Brakes



04-002-00

1.	82-03763-000	Camshaft, RH Frt	1	17.	82-03344-000	Lockring, Camshaft	2
	82-03769-000	Camshaft, LH Frt	1	18.	82-03501-000	Gasket, Chamber Brkt	2
2.	82-03379-000	Washer, Spacer	2	19.	82-07932-002	Spider Asm, LH Frt	1
3.	82-03455-000	Pin, Brake Shoe Anchor	4		82-02392-000	Spider Asm, LH Frt w/Seal	1
4.	82-02241-000	Seal, Camshaft	4		82-02393-002	Spider Asm, RH Frt	1
5.	82-03288-000	Bushing, Anchor Pin	4		82-02393-000	Spider Asm, RH Frt w/Seal	1
6.	82-03294-000	Bushing, Camshaft	4	20.	82-03283-000	Pin, Shoe Retainer	4
7.	82-03835-000	Spring, Shoe Retainer	4	21.	82-03837-000	Spring, Shoe Retainer	2
8.	82-02406-000	Shoe Asm, Frt Brake	4	22.	82-00156-000	Bolt, Spider Mtg	16
9.	82-06026-000	Kit, 6" Brake Lining	1		82-04477-000	Washer, Flat	32
10.	82-03504-000	Roller, Brake Shoe	4		82-03173-000	Locknut, Spider Mtg	16
11.	82-03871-000	Retainer, Roller	4				
12.	82-00194-000	Screw, Cam Brkt	8				
	82-03417-000	Washer, Cam Brkt	8				
13.	82-00197-000	Brkt Asm, LH Chamber	1				
	82-04729-002	Brkt Asm, LH Chamber w/o Bushing	1				
	82-00994-000	Brkt Asm, RH Chamber	1				
	82-04729-001	Brkt Asm, RH Chamber w/o Bushing	1				
	82-00872-000	Fitting, Grease	2				
14.	82-03396-000	Washer, Outer Spacer	2				
15.	82-02164-000	Adjuster, Manual Slack	2				
16.	82-03356-000	Washer, Inner Spacer	6				

Front Brake Chamber



PA-03-017

1.	82-06191-006	Cover Asm, Chamber	1
2.	82-06191-005	Diaphragm	1
3.	82-06191-001	Rod Asm, Push	1
4.	82-06191-002	Spring, Return	1
5.	82-06191-004	Clamp Asm, Chamber	1
6.	82-06191-003	Body Asm, Chamber	1